

How to fill text in specified size?

05/14/2024 21:08:10

FAQ Article Print

Category:	FAQ in English::KOMPAS-3D FAQ::Text input and editing FAQ	Last update:	07/04/2008 17:42:07
State:	public (all)		

Keywords

text, size

Problem (public)

How to fill text in specified size?

Solution (public)

In dialog "Service-Format" you should make options "Modify Text Width Factor" and " Modify Line Spacing" active, during text entering. After that set text width and height in proper fields of the same dialog.